


<EBS-010 cable technical information>



* STATUS LED color		
- WARMING UP		(Red blinking)
- READY		(Green ON)
- Analyzing		(Orange ON)
- Flow error		(Red ON)